

# **Level Module** (Head Mounted Transmitter) for Conductive Level Probes



measuring monitoring analysing

# LNR



- Mounting inside the level probe
- Direct connection to the PLC
- No level device required in the control cabinet
- Completely assembled encapsulated module
- PNP switch output, short-circuit-proof
- Adjustable sensitivity
- Electrode supply: AC voltage
- Power supply 24 V<sub>DC</sub>



KOBOLD companies worldwide:

ARGENTINA, AUSTRIA, BELGIUM, BULGARIA, CANADA, CHILE, CHINA, COLOMBIA, CZECHIA, DOMINICAN REPUBLIC, EGYPT, FRANCE, GERMANY, GREAT BRITAIN, HUNGARY, INDIA, INDO-NESIA, ITALY, MALAYSIA, MEXICO, NETHERLANDS, PERU, POLAND, ROMANIA, SINGAPORE, SOUTH KOREA, SPAIN, SWITZERLAND, TAIWAN, THAILAND, TUNISIA, TURKEY, USA, VIETNAM

KOBOLD Messring GmbH Nordring 22-24 D-65719 Hofheim/Ts. Head Office:

+49(0)6192 299-0

+49(0)6192 23398 info.de@kobold.com www.kobold.com





### **Description**

The KOBOLD level module LNR evaluates levels in conductive level probes. The module can be mounted in the sensor housing.

A 3-wire connection is used and the conductive connection between probe stem and ground is converted to a 24  $\rm V_{\rm DC}$  switching signal. The sensitivity is adjustable in 4 steps. The output signal can be evaluated and processed by a PLC. The switching state of the output is inverted by reversing the polarity of power supply. In addition, a LED shows when the level is reached.

Direct mounting to the measuring point means that no additional level device is required in the control cabinet. This means lower installation costs, minimum wiring and a high degree of

noise immunity. Due to the 24  $V_{\rm DC}$  supply and the active output the transducer for top mounting is specially designed for level measurement with a PLC.

#### Setting the full /empty Signal Function

The jumper must always be plugged in for one function. The output function (full / empty signal) is switchable via the polarity of the supply voltage.


Power supply		Sonde	Output	LED
Connection 1	Connection 2		Connection 3	
0 V	+Vs	immersed	U <sub>aus</sub>	on
		dry	0 V	off
+Vs	0 V	immersed	0 V	off
		dry	U <sub>aus</sub>	off

## **Setting the Sensitivity**

- 1. Cover probe with the medium to be measured.
- 2. Insert sensitivity jumper on position 0.1 k $\Omega$ .
- 3. If the probe LED does not light up, try positions 1 k $\Omega$ , 10 k $\Omega$  and 100 k $\Omega$  in succession (see drawings), until the probe LED is illuminated.

Step	Sensitivity	Connection 4	Jumper position
1	100 Ω	+Vs	inside
2	1 kΩ	+Vs	outside
3	10 kΩ	open	outside
4	100 kΩ	GND	outside

#### **Wiring Diagram**



- 1 Power supply: +Vs / GND
- 2 Power supply: GND / +Vs
- 3 Output: transistor PNP ( $U_{off} = +Vs 1 V$ )
- 4 Sensitivity: +Vs / GND / open
- 5 Electrode 1: Ground electrode or wall of vessel
- 6 Electrode 2: Measuring sensor electrode

#### **Technical Details**

Power supply:  $15...36 \, V_{DC} / 15 \, \text{mA}$ 

Output: PNP transistor output

(open collector),  $U_{off} = +Vs - 1 V$ 

max. 50 mA, hort-circuit-proof

Function: full / empty signal

(switchable by jumper)

Switching delay: approx. 1 s

LED-display: signalling in case of medium

contact

Sensitivity: approx.  $0.1/1/10/100 \text{ k}\Omega$ ,

setting via input control and jumper

Electrode voltage: approx. 2 V<sub>AC</sub> / 600 Hz

Operating temperature: -20...+80°C

Humidity: 0...90%, non-condensing

Housing: Makrolon®

Dimensions: Ø 44.5 x 21 mm

Weight: approx. 40 g

Order Detail: LNR-K1